

Horton Humidifier

(New) plastic trash can with tight-fitting lid

Smaller plastic container (without lid) that fits completely into the trash can

Blotters

1. Place documents in the smaller container. (Fragile documents should NOT be stood on their edges.)
2. Place the smaller container in the trash can.
3. Thoroughly wet blotters with water and place them in the space between the two cans.
4. Cut a blotter to fit tightly into the lid of the trash can. (This is to prevent condensation on the lid and consequent dripping onto the documents.)
5. When documents have relaxed, take them out and dry them as usual.
6. Dry out the blotters, both cans and the lid (in sunlight, if possible). Mold will be a problem if thorough drying is not done after each use.

